

approximately 1/8" above the adjacent masonry surface. Follow manufacturer's instructions.

4. Set preformed tee cap strip into the sealant bed, pressed down firmly to the stone surface so bonding grooves are solidly filled and no voids exist between tee cap and masonry.
5. Clean off excess sealant compound using a putty knife and leave adjacent masonry clean.
6. Carefully remove masking tape from adjacent surfaces.

END OF SECTION