




TYPE A (THE FLAT CAP)



TYPE B (90° COVE CAP)



HORIZONTAL



TYPES B-2, B-3 & B-4 ARE USED IN HORIZONTAL AND/OR VERTICAL (PERPENDICULAR) ANCHORAGE.
B-5 AND B-8 ARE FOR PERPENDICULAR ANCHORAGE